

Fitting of the NET Audio NOS Board.

The NET Audio NOS board is very simple to fit. First remove the SAA7220 from your circuit board using a solder sucker or solder braid. Once removed fit the NOS board in its place noting the configuration of the pins. Pin 1 of the NOS board is shown on the diagram below. There is no need to remove the crystal and its associated parts from the CD players circuit board as these pins are not connected on the NOS board in standard form.

Once the NOS board is fitted in the correct orientation, solder the pins to the underneath of the circuit board as normal.

You now have an upgraded CD player which will give many hours of musical enjoyment.

