

Fitting Instructions For the NET Audio Quad 33 Primp Upgrade.

- 1) Remove all connections from the pre-amp.
- 2) Remove the two screws from the rear of the pre amp and carefully slide the outer cover off.
- 3) Inside there will be 3 plug in cards, one on the left (looking from the front) and two twin cards at the right rear.
- 4) By pulling upwards on these cards, remove them from the 33 chassis.
- 5) Insert the new upgrade cards in the same sockets that the originals have been removed. The connectors and circuit boards are identical in outline.
- 6) Remove the tape adapter card from the rear middle of the 33 (looking from the back of the unit). Be careful to lift the small hinged door before removal.
- 7) With the hinged door up, push the new tape adapter card into the rear of the pre amp, making sure it is aligned with the connector correctly before firmly but gently pushing home.
- 8) Replace the outer cover and refit the screws.
- 9) Reconnect to your Hi-fi and with connect the regulated power supply to the socket on the tape adapter upgrade board.
- 10) With the volume turned down, switch the power on to the regulated power supply.
- 11) You can either have the 33 running from the regulated power supply and/or the mains. Some prefer the later as the 33s power output sockets can then be used to power the power amplifier and/or the regulated power supply. This allows the regulated power supply to be swathed on and off with the 33s normal on/off control.
- 12) Your upgraded 33 should now be fully functional.